




KEYA®

TRONIC SLIM



1. OPEN and CLOSE

1.1 Multiuser version

Open and close by 4-digit code. The code is erased every time the lock is opened, being available for a new use.

1.1

Close:




Upon closing, confirmation will sound and the Green Led will light up.

Open:



Upon opening, confirmation will sound and the Green Led will light up.

In case of error, 3 short beeps will sound and the Red Led will blink 3 times.
The described acoustic signal are not fulfilled for the Tronic SLIM setting in silent mode.



1.2 Single user version

Access through 4-digit code. The code, previously assigned, will be kept for a single user.

1.2

In single user mode, Tronic Slim will remain closed.

Open:



Upon opening, confirmation will sound and the Green Led will light up.


Close:

Automatic in 2 seconds or by pressing



Upon closing, confirmation will sound and the Green Led will light up.

In case of error, 3 short beeps will sound and the Red Led will blink 3 times.
The described acoustic signal are not fulfilled for the Tronic SLIM setting in silent mode.



2. CHANGE USER CODE

This functionality is only available in single user version.


In Multi-User version, after the process, error will sound with 3 short beeps and the red Led will blink 3 times.

2

Press for 3 seconds



- 1- Press for 3 seconds
- 2- Confirmation will sound and the Green Led will turn on.
- 3- Enter CURRENT Code during the flashing of the Red Led.
- 4- Press confirmation will sound and the Green Led will light.
- 5- Enter NEW Code during the flashing of the Red Led.
- 6- Press confirmation will sound and the Green Led will light.



In case of error, 3 short beeps will sound and the Red Led will blink 3 times.
The described acoustic signal are not fulfilled for the Tronic SLIM setting in silent mode.

3. OPEN WITH MASTER CODE

3



MASTER code


-30S INSPECTION MODE	+30S USER ERASED
----------------------------	---------------------

INSPECTION MODE: User code will be deleted

- 1- Enter the 5-digit Master Code.
- 2- Confirmation will sound, the Green Led will light up and Tronic Slim will open.
- 3- Press within 30 seconds and Tronic Slim will close.

DELETE USER CODE: User code will be deleted.


- 1- Enter the 5-digit Master Code and press
- 2- Confirmation will sound and Tronic Slim will open.
- 3- Wait 30 seconds until the 8 Beeps sounds and the Green Led blink. Tronic Slim will remain open.



In case of error, 3 short beeps will sound and the Red Led will blink 3 times.
The described acoustic signal are not fulfilled for the Tronic SLIM setting in silent mode.


4. MASTER CODE CHANGE

4- Press during 3 seconds



- 1- Press during 3 seconds
- 2- Confirmation will sound and the Green Led will turn on.
- 3- Enter CURRENT Code during the flashing of the Red Led.
- 4- Press confirmation will sound and the Green Led will light.
- 5- Enter NEW Code during the flashing of the Red Led.
- 6- Press confirmation will sound and the Green Led will light.

In case of error, 3 short beeps will sound and the Red Led will blink 3 times.
The described acoustic signal are not fulfilled for the Tronic SLIM setting in silent mode.



5. MASTER ELECTRONIC KEY

5



INSPECTION MODE : User code will not be erased.

- 1- Connect Master Key (Blue) to Tronic SLIM.
- 2- Tronic Slim will open, 2 beeps will sound and the green LED will blink 2 times.
- 3- Disconnect Master Key (Blue).
- 4- Press before 30 seconds and Tronic Slim will close.

DELETE USER CODE : User code will be deleted.

- 1- Connect Master Key (Blue) to Tronic SLIM.
- 2- Tronic Slim will open, 2 beeps will sound and the green LED will blink 2 times.
- 3- Disconnect Master Key (Blue).
- 4- Wait 30 seconds until the 8 Beeps sounds and the Green Led blink.
- 5- Enter New User Code.

In case of error, 3 short beeps will sound and the Red Led will blink 3 times.
The described acoustic signal are not fulfilled for the Tronic SLIM setting in silent mode.

* Ask your KEYA sales representative for more information on the key and necessary accessories

6. CONFIGURABLE PARAMETERS – KEYA CONTROL*

6



KEYA Control



KEYA Control App



Automatic openings:

- 1- Limited use time: The lock will open after the set time
- 2- Specific Time: The lock will open at the scheduled time
 - HH:MM, Day of the week /Every day /Mon to Fri, Leave Tronic Slim open or Closed

Volume:

High / Low: Sound when pressing the numeric keys (0-9) and Confirmation or Error.
 Off: Green LED on when pressing the numeric keys (0-9) and LED flashing Confirmation or Error

Closed position indicator LED:

Enabled / Disabled: Flashing of the red LED when Tronic SLIM is closed

Codes:

User / Master: Check the codes stored in Tronic SLIM

Battery level

Number of Operations

* Ask your KEYA sales representative for more information

7. PARAMETER KEY

7



Pre-configured keys:

- 1- Factory parameters already configured *
- 2- Connect the black key to the Tronic SLIM
- 3- Tronic SLIM will sound 2 beeps and the green LED will blink 2 times
- 4- Disconnect the black key to the Tronic SLIM

Compatible with Software:

- 1- Connect the key to the PC and run KEYA Control *
- 2- Modify the parameters with KEYA Control *
- 3- Key Configured successfully.

* Ask your KEYA sales representative for more information

In case of error, 3 short beeps will sound and the Red Led will blink 3 times.
 The described acoustic signal are not fulfilled for the Tronic SLIM setting in silent mode.

8 Specifications

8.1 Battery replacement

Attention!

The batteries must be replaced when the system communicates low battery with three flashes of the orange led. A T20 Torx is required for the top housed screw. The change must always be made in less than 5 minutes and with the BATPACK switched on (otherwise the internal clock would lose the time).



Torx T20

8.2 Technical specifications

IP (keypad/lock)	---/45
Operating temperature	-5°C < > +70°C
Cam	> 45Kg
Ultraviolet rays	> 10000h
Vibración	10 - 200 Hz 2g
Lifecycles	> 200000 cycles
Electrostatic discharge	8000 V
Batteries	x4 LR6/AA
Battery life	90000 cycles or three years



WIRELESS DIRECTOR



RoHS



Sistema de
Gestión
ISO 9001:2015

www.tuv.com
ID: 9105066651

